



Aqua Spa Pak
#201 – 26633 Gloucester Way
Aldergrove, BC V4W 3S8
Phone: 604-856-7711
Fax: 604-856-7744
orders@aquaspapak.com

CTI DIGITAL SIGNETIC GENERAL FACTORY PROGRAMMING PROCEDURE rev:01

Specific setting ranges may vary with custom software

Power up system and "Pur" is displayed on topside panel for 30 seconds while in purge mode. Regular operation will then assume.

Press Heat and Light key until " r--" appears." r--" is the revision level of the system that is being programmed. This is for system ID and is not adjustable. This revision level may change as additions or changes are made to the system.

Press Heat key again and C or F will appear. Press Jets One key to toggle from C to F. Celsius or Fahrenheit. When choice is made press Heat key to go to next mode.

C 2,4,5,6,7, or 12 will appear. Press Jets One key to change the value for filtration cycle within a 12-hour period. Circ pump systems should be set to C12. Press Heat Key to go to next mode.

HC (High Current), LC (Low Current), or 230 will appear. Press Jets one key to toggle from HC, LC or 230 operation. HC operation allows heat capability at any time where LC operation will drop out the heater if Pump 1 high speed, Pump 2 low or high speed, or the blower is activated. Pump 1 hi speed and Pump 2 will be able to run at the same time with no heat. Pump 1 and or Pump 2 will override the blower in this set up.

230 is for European configuration that runs the equipment in combinations that allow a minimum amperage draw. Press Heat Key to go to next mode.

100 to 106 or 38 to 41 will appear depending on the Celsius or Farenheight set up. Press Jets One key to change value for maximum temperature set capability for regular use. 104 is recommended. When choice is made press Heat Key to go to next mode.

P 11, P12 or P10 will appear. Press Jets One to set pump operation. P 11 = Pump 1 single speed. P12 = Pump 1 two speed. P10 = Pump 1 Two speed, low, high, off and is for two speed primary pump operation while using a circ pump. When choice is made press Heat key to go to next mode. **Do not run P12 if using circ pump**

P 21 or P 22 will appear. Press Jets One key to toggle between 1 or 2 to set pump operation. P 21 = Pump 2 single speed. P 22 = Pump 2 two speed. When choice is made press Heat Key to go to next mode.

P 6 or P 12 will appear. Press Jets One key to toggle between P 6 or P12 to set the system purge time. P 6 = Purge every 6 hrs. P 12 = Purge every 12 hrs. **Press heat key to go back to run mode to lock in new program, otherwise it will default to previous setting.**

THESE PROGRAMMING INSTRUCTIONS ARE FOR THE INSTALLER OF THE SPA PAK AND SHOULD NOT BE ISSUED TO THE END USER.